



Packed with smart features, the versatile GK-S and GK-Plus indicators provide an intuitive user interface, a bright display with large, 1.6" / 40mm-high digits and quick results. The built-in checkweighing function with color-changing display allows users to easily view if samples are above, below or at set targets. Whereas the GK-S features a simpler, 5-button interface, the GK-Plus touts a full numeric keypad that performs a variety of applications (check counting, percentage weighing, net/total weighing and dynamic weighing) on the same indicator. Housed in solid ABS plastic, these indicators are sturdy and simple to clean. Both are equipped with a wall bracket for easy, secure mounting.

*Weighing and checkweighing tasks accomplished with simple versatility*



## Features

- Capacity tracker built into display for easily monitoring possible overloads
- Selectable language for printing
- Hold function freezes the displayed weight, allowing time to elapse without losing the result
- Auto power-off to save energy
- Memory accumulation totals results
- Vivid, backlit LCD easily visible in any lighting conditions
- Large, 1.6" / 40mm-high easily legible digits on a bright background
- Solid ABS housing is durable for industrial use
- External calibration allows for verification and adjustment with weights
- Optional USB interface simplifies data communication
- RS-232 interface provides speedy connection to computers and printers
- Color-changing backlight in checkweighing mode to show if under, over or within acceptable limits
- GK-S features a simple, 5-key operation allows for easy set up and use
- GK-Plus offers a full numeric keypad for quick and easy entering of check weighing limits
- Wall-mount bracket for placing indicator on vertical surface
- 1:1,600,000 Internal counting resolution for precise results
- Rechargeable battery included for operation almost anywhere\* (Optional on GK-S)
- Selectable digital filtering for animal/dynamic weighing enables consistent results for moving subjects\*

## Applications

- Weighing
- Checkweighing
- Percentage weighing
- Check counting
- Parts counting
- Dynamic / animal weighing\*
- Net total weighing\*

### About ADAM:

For more than 50 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

## Product Details

Model	GK-S	GK-Plus
Capacity	Selectable	
Readability	Selectable	
Weighing Units	g, kg, lb, oz, lboz	
Internal Counting Resolution	1:1,600,000	
Interface	RS-232, Optional USB	
Calibration	External	
Display	Backlit LCD with 1.6" / 40mm-high digits	
Power Supply	12VDC 800mA adapter, Optional internal rechargeable battery	12VDC 800mA adapter, internal rechargeable battery
Operating Temperature	-10° to 40°C	
Housing	ABS Plastic	
Overall Dimensions (DxWxH)	8.7" x 12.4" x 8.3" / 300 x 230 x 210mm	

## Accessories

### Item Number ..... Description

- 2050013351..... Tripod Indicator Stand
- 3052010526 ..... In-use wet cover
- 3074010266 ..... RS-232 cable
- 3074010507 ..... RS-232 to USB adapter
- 1120015779 ..... ATP2 Thermal Printer
- 3126011263 ..... ATP2 paper
- 3126011281 ..... ATP2 paper (x10)
- 60002028 ..... AdamDU Data Collection Program
- 700660290 ..... Calibration certificate

## Key Accessories



### Tripod Indicator Stand

Stabilize a freestanding indicator that is separated from a scale. With sturdy yet lightweight aluminum construction, the stand is easy to transport.



### AdamDU Data Collection Program

Adam DU quickly collects information from up to eight Adam balances simultaneously. An easy-to-use interface with a main command window allows the user to view and manage data capture sessions.

Supplied by